


IP-201-YxZ-Xv I²C Bus Multiplexer Cabinet AC Line Voltage Selection

Change the voltage selection card as indicated below:



Voltage Selection Unfiltered and Filtered Models



Open cover door and rotate fuse-pull lever to left. Select operating voltage by orienting voltage selection card, desired voltage on top left side. Push card firmly into module slot. Rotate fuse-pull lever back into normal position and re-insert fuse into holders. Use caution in selecting correct fuse value.